## SAW FRAMES




| MSA  | Depth | Kg    |  |  |
|--|-------|-------|--|--|
| 04.311-075                                       | 75 mm | 0.140 |  |  |
| Rigid steel fixed saw frame with plastic handle. |       |       |  |  |

ADJUSTABLE

| MSA        | Depth  | Kg    |
|------------|--------|-------|
| 04.316-075 | 75 mm  | 0.175 |
| 04.316-100 | 100 mm | 0.185 |
| <b>D</b> : |        |       |


Rigid stainless steel adjustable saw frame with plastic handle. *Steel tension screw to tighten the saw blades.* 



| MSA        | Depth  | Kg    |
|------------|--------|-------|
| 04.315-060 | 60 mm  | 0.150 |
| 04.315-070 | 70 mm  | 0.150 |
| 04.315-080 | 80 mm  | 0.153 |
| 04.315-100 | 100 mm | 0.170 |
| 04.315-120 | 120 mm | 0.180 |
| 04.315-150 | 150 mm | 0.190 |
| 04.315-200 | 200 mm | 0.210 |

Saw frame made of rigid and resistant steel, with black varnished wooden handle.

Delivered with 1 toothed plate and fixing screws to firmly hold the saw blades in place. Tension screw to tighten the saw blades.



| MSA        | Depth  | Kg    |
|------------|--------|-------|
| 04.310-070 | 70 mm  | 0.145 |
| 04.310-080 | 80 mm  | 0.150 |
| 04.310-100 | 100 mm | 0.155 |
| 04.310-120 | 120 mm | 0.165 |

Saw frame made of rigid and resistant steel, with black varnished wooden handle.

Delivered with 1 toothed plate and fixing screws to firmly hold the saw blades in place.

## Spare parts for MSA04.310-x and MSA04.315-x :

| MSA      | Item                            | Kg    |
|----------|---------------------------------|-------|
| 04.310-A | (1) Saw blades screw            | 0.007 |
| 04.310-B | (2) Upper screw                 | 0.005 |
| 04.310-C | (3) Fixing plate for saw blades | 0.002 |
| 04.310-D | (4) Washer for saw blades       | 0.001 |



