Tools for Swatch® battery covers.





MSA			
07.010	120 mm	Gent	0.072
07.012	120 mm	Medium	0.072
07.011	120 mm	Lady	0.071

Tool for Swatch® battery covers.









MSA		
03.620-GENT	Gent	0.015
03.620-MED	Medium	0.015
03.620-LADY	Lady	0.015

Interchangeable key to fit in the handle MSA03.620-A.





MSA	
03.620-A	0.060

Hexagonal handle on which all types of here above keys and those illustrated on chapter 03 can be fitted.



See chapter PERF.