

ELMA® solutions.



MSA	Product	Contents
26.845	WF PRO	2.5 litres
26.846	WF PRO	10 litres
26.847	WF PRO	30 litres

ELMA® WF PRO is a cleaning solution microemulsion-based detergent for use with mechanical precision parts, such as dismantled and assembled watch movements, in cleaning systems with or without ultrasound. It cleans gently with excellent results. It provides good material compatibility and cleans, removes resins and dissolves oxides (brightens) in a single step. This solution helps to ensure a very long service life.



MSA	Product	Contents
26.848	SUPROL PRO	2.5 litres
26.849	SUPROL PRO	10 litres
26.850	SUPROL PRO	30 litres

ELMA® SUPROL PRO is a non-aqueous detergent for rinsing precision parts, such as dismantled and assembled watch movements, after they were cleaned. Cleaning solutions like ELMA® WF PRO rinse off completely. This product evaporates quickly without residue and ensures that lubricants can be applied evenly. In aqueous cleaning of precision metal parts, it can also be used to displace water before drying.



MSA	Product	Contents	Kg
26.828	1:9	1/2 litre	0.525
26.830	1:9	1 litre	1.200
26.829	1:9	2.5 litres	5.300

ELMA® 1:9 cleaning solution. Aqueous concentrate for cleaning disassembled watch parts and high precision metal pieces. Hardened oils are carefully and rapidly removed. Gives light effect to alloy gold and brass.



MSA	Product	Contents	Kg
26.824	CLEAN 225 SONIC	1 litre	1.200
26.823	CLEAN 225 SONIC	5 litres	6.000
26.825	CLEAN 225 SONIC	10 litres	11.000

ELMA® CLEAN 225 SONIC is an alkaline liquid concentrated cleaning solution for metals after a mechanical work.



MSA	Product	Contents	Kg
26.800	SUPER CLEAN	1 litre	1.100

ELMA® SUPER CLEAN is an aqueous, ammonia-based cleaning concentrate for universal cleaning of gold, silver and jewellery that contains hard gemstones.

It brightens tarnished gold, silver or alloys and removes grease, emulsions, dust and sweat residue.

Use diluted between 3 and 10%.



MSA	Product	Contents	Kg
26.820	CLEAN 75	1 litre	1.100

ELMA® CLEAN 75 is a cleaning concentrate solution used in ultrasonic baths to remove dirt particles, grease and oils (plant-, animal- and mineral oil-based fats) as well as residues from grinding, polishing or lapping (Parisian Red and other polishing pastes and waxes).

It cleans every piece of jewellery thoroughly and brightens precious and non-ferrous metal parts. This product is not suitable for jewellery made of zinc, aluminium, light alloys or soft/delicate stones such as pearls, corals, opals, etc.

Use diluted between 5 and 10%.



MSA	Product	Contents	Kg
26.822	ULTRA CLEAN	1 litre	1.200

ELMA® ULTRA CLEAN is a cleaning concentrate solution, cyanide-free and mildly alkaline. It gently cleans gold, platinum or iridium jewellery (also with precious stones) in immersion baths with or without ultrasound.

It reliably removes wax, resin, grease, polishing agents, machining emulsions, sweat and dust, and gives an ultra-bright shine to gold jewellery.

Use diluted between 5 and 20%.



MSA	Product	Contents	Kg
26.810	NOBLE CLEAN	1 litre	1.200
26.811	NOBLE CLEAN	10 litres	10.800

ELMA® NOBLE CLEAN cleaning solution. This acidic detergent cleans intensively and brightens jewellery and alloys made from precious metal within seconds. The cleaner is also available in a handy 1-litre round bottle with a wide neck for immersing jewellery and cutlery. After you rinse the precious metal parts with cold water, the temporary anti-tarnish finish will prevent tarnishing for a long time.

Elma Noble Clean is cyanide-free and provides relatively equal results to highly toxic jewellery cleaners containing cyanide.

Ready for use bath.